


Part Number	Gi1
Description	Gi1 Glass Lens
Product Picture	
Materials	Glass
VLT	65%
CE Laser Etched Specifications	900-925 DIR LB4 925-1000 DIR LB5 1000-1025 DIR LB6 1025-1400 D LB6 + IR LB7 1400-2400 DLB4 + ILB5 2770-10600 DI LB4 INVO CE
OD Laser Etched Specifications	900-925nm (OD4) 925-1000nm (OD5) 1000-1025nm (OD6) 1025-1400nm (OD7) 1400-2400nm (OD5) 2770-10,600nm (OD4) 10,600nm (OD5)
Instructions for Cleaning and Disinfection	Use the enclosed cleaning cloth and mild soapy water. Rinse eyewear thoroughly with clean warm water. Dry with the enclosed clean, soft cloth. Store the eyewear within the provided case, in a dry and cool place. Do not use abrasive chemicals or alcohol to clean or disinfect.
Instructions for Use	<ul style="list-style-type: none"> a) It is the user's responsibility to make sure that the laser radiation eyewear is appropriate for the laser source being used. If you have questions consult the laser manufacturer or your LSO. b) This laser eyewear is intended to protect against accidental and temporary exposure to laser exposure. c) Due to the tinted and colored filter, recognition of warning lights or warning signals can be impaired. d) If the eye-protectors and filters used to protect against laser radiation have been damaged, scratched, or undergone color change, they shall not be used anymore and should be replaced. e) Laser eyewear must be worn by anyone within the nominal hazard zone of that laser. f) User's are at risk of exposure to laser radiation due to reflection from reflective parts (including eye-protectors and filters), tilting or misalignment of optical components. Laser beams that accidentally reflect of objects can cause damage. g) User's shall never look directly at a laser beam. h) For additional information regarding specific data, and declaration of conformity visit https://innovativeoptics.com/gi1-laser-glasses-frames/ i) Do not modify this product without prior approval from the manufacturer. j) Do not clean eyewear with abrasive cloths or chemicals. k) We recommend use for a period of 5 years. The duration of use depends on various factors such as use, cleaning, storage and maintenance. Frequent inspections and replacement is recommended if damaged. l) The eyewear is intended for protection against laser radiation and only capable of providing protection if the specifications appropriately protect against the laser requirements. Performance of the eyewear depends on various factors such as cleaning, storage, and maintenance.
Warning	Materials that contact the wearer's skin may cause allergic reactions to susceptible individuals.
Revision Date	1.1.2022

